

# BRIGGS WEIGHT INDICATORS

Designed to fit any type  
of forklift truck

Suitable for all makes and models  
Pressure Indicators  
Improve forklift safety  
Easy installation



**BRIGGS**  
EQUIPMENT

IN PARTNERSHIP WITH

 **FTC**  
Fork Truck Control





**PRESSURE INDICATORS**

**IMPROVE FORKLIFT SAFETY**

# WEIGHT INDICATORS

---

### **DO I NEED A WEIGHT INDICATOR?**

If you are handling loads that are over dimensional such as timber packs, scrap metal, loads supplied in stillages or pallets etc. if you receive goods which do not have a tare weight marked on them, you need to protect your forklift from accidental overload.

### **“BRIGGS” WEIGHT INDICATOR SYSTEM**

Designed to suit all makes and models of forklift trucks. This trouble free, easy to read design has taken over from the old dial type indicators.

The PWI-25/100 system unit comes with a history of reliability and excellent backup service.

### **“BRIGGS” PRESSURE WEIGHT INDICATOR**

The operator can see at a glance if the load is within the safety limits of the fork lift truck potentially reducing the risk of overloading.

### **FORKLIFT SAFETY**

It is the responsibility of both management and operators to see that their forklift truck is not overloaded.

The forklift manufacturer must supply a rating label on every forklift truck that shows the capacity at a given load centre and fork height, but this does not help the operator if they do not know what the load weight is. A weight scale will tell immediately what weight you are picking up.

## INSTALLATION KIT

All weighing kits come complete with a universal mounting bracket, an assortment of hydraulic and electrical components to make the installation of your Briggs Weight Indicator simple.

### THE KIT CONTAINS:

- 1 x MK2 Digital Weight Display Unit
- 1 x Transducer And Cable Assembly
- 1 x 12 Volt, Power Cable Assembly
- 1 x Universal Mounting Bracket

### DISPLAY OPTIONS:

- Automatic and manual zero correction
- Gross/net weighing
- Automatic tare and manual tare weight entry
- Totalisation with sequence number
- Error message in display
- Automatic switch off
- Overload protection 300%

### CAPACITY

Capacity to fit the capacity of the truck

### GRADUATIONS

@ a capacity 2,500kg... in 5kg steps @ a capacity 5,000kg... in 10kg steps @ a capacity 10,000kg... in 20kg steps

### SENSOR TOLERANCE



2%

### SYSTEM TOLERANCE

2% of full scale (depending on lifting capacity of the truck)

### INDICATOR LCD CONTROLS

4 Functions / auto on/off when not in use



### EASE OF INSTALLATION

- A. Transducer is installed into the mast hydraulic line [1].
- B. The digital display unit [2] complete with chock proof circuit is installed in a comfortable viewing position to suit the driver or optional position [3].
- C. A power source to the display unit is wired into the key switch.
- D. Unit is then calibrated using a test weight for accuracy.

Briggs Ltd can provide a full training and installation programme. For further information please contact us through our web site



**EASY INSTALLATION**

**SUITABLE FOR ALL MAKES AND MODELS**



Briggs Equipment UK Ltd ■ Orbital Way ■ Cannock ■ Staffordshire ■ WS11 8XW ■ United Kingdom  
Tel: 03301 23 98 50 ■ email: [info@briggsequipment.co.uk](mailto:info@briggsequipment.co.uk) ■ [www.briggsequipment.co.uk](http://www.briggsequipment.co.uk)