

Our Adjustable Snow Plough fits to the truck by the following means.

Simply; ensure the screw clamps on the pockets are unscrewed to allow the forks to enter. Drive the truck into the pockets as far as possible, then simply tghten the clamps, ensuring adequate retention is achieved.

To adjust thr blade angle; remove the lynch pins from the2 removable drop pins, then move the blade to the desired postion. Replace both drop pins and re-fit the lynch pins.

Adjustable Snow Ploughs allow simple adjustment enabling the plough to sweep left, right or straight ahead. Castors and rubber blade inserts are fitted as standard.

Model Ref.		A		В		С	D
ASP 1525 RC		1525mm		550mm	550mm		804mm
ASP 1830 RC		1830mm		550mm	550mm		804mm
ASP 2130 RC		2130mm		550mm	1	380mm	804mm
Model Ref.	V	Veight	C of G			$\sim$	1
ASP 1525 RC	1	L33kgs	752mm		0	- F	7 .
ASP 1830 RC	1	l42kgs	773mm				A
ASP 2130 RC	150kgs		789mm		$\sim$	8	The second

Max Fork Size 140 x 60mm Section